

# Innovative Replacement Rubber Sleeves™

## Usage Instructions



Above shows heavy overspray on hook.



Grind overspray off of hook (grind down to bare metal).



Slide rubber sleeve onto hook and apply electrical tape as shown to secure sleeve onto hook. When overspray gets excessive, cut tape along bottom edge and replace with new sleeve.

Rubber Replacement Sleeves are available for the following products:

**Door-Fender Single**  
**Door-Fender Double**

Part # I-DF-RS12

Quantity: 12 sleeves per package

**Innovative Ultrarack**

Part # I-URPS-RS20

Quantity: 20 sleeves per package

**Innovative Ultrarack Center Hook**

Part # URPS-CHR10

Quantity: 10 sleeves per package

If you have any comments, questions or concerns about our products, please contact us at 1-866-438-4884 or 651-415-0733.  
[www.innovativetools.com](http://www.innovativetools.com)