

Innovative Spray Gun Cabinet Mounting Instructions

Leave one to two inches top clearance for flip-up door



1. Unbolt back panel from cabinet
2. Level back panel in desired location
3. Mark holes on wall as shown above
4. Use the included multi-purpose drill bit
5. Fasten back panel to wall with supplied anchor bolts, then mount cabinet to back panel and tighten bolts.